

KEEN Demonstrator

Project Status - Monthly Report

April 2023

Follow up points

Last week activities:


- Camera configuration and image capturing
- Camera calibration finding the parameters
- Color detection; Measuring the color present in the frame

This week activities:

- Liquid volume measurement using OpenCV color detection (slide #3) **Short term problem approach**
- Machine learning algorithm framework for Liquid Volume Estimation (slide #4) **Long term problem approach**
- ML algorithm Framework layers (slide #5)

Volume detection using OpenCV color detection

- Volume proportion of the liquid is studied using color detection algm.
- Approximate results were obtained for liquid, glass area and liquid proportion.
- If it's a cylindrical glass will get even more accurate result as the crop ROI frame is rectangle



```
ScaDS > volproportion.py > ...  
16 glass_roi = cv2.selectROI(img)  
17 glass_img = img[int(glass_roi[1]):int(glass_roi[1]+glass_roi[3]),  
18 | | | int(glass_roi[0]):int(glass_roi[0]+glass_roi[2])]  
19  
20 # Convert to grayscale and preprocess the image  
21 gray = cv2.cvtColor(glass_img, cv2.COLOR_BGR2GRAY)  
22 gray = cv2.GaussianBlur(gray, (5, 5), 0)  
23 _, thresh = cv2.threshold(gray, 0, 255, cv2.THRESH_BINARY+cv2.THRESH_OTSU)  
24  
25 hsv = cv2.cvtColor(glass_img, cv2.COLOR_BGR2HSV)  
26 #lower_red = np.array([0, 50, 50])  
27 upper_orange = np.array([20, 255, 255])  
28 lower_orange = np.array([5, 0, 0])  
29 mask = cv2.inRange(hsv, lower_orange, upper_orange)  
30 cv2.imshow('maskimage', mask)  
31 #cv2.imwrite('maskimage', mask)  
32  
33 # Find the contours of the liquid mask  
34 contours, hierarchy = cv2.findContours(mask, cv2.RETR_EXTERNAL, cv2.CHAIN_APPROX_SIMPLE)  
35 max_contour = max(contours, key=cv2.contourArea)  
36  
37 # Compute the area of the liquid mask and the area of the entire glass  
38 liquid_area = cv2.contourArea(max_contour)  
39 glass_area = glass_img.shape[0] * glass_img.shape[1]  
40  
41 # Calculate the proportion of liquid in the glass  
42 liquid_proportion = liquid_area / glass_area  
43 print('liquid area: ', liquid_area)  
  
PROBLEMS OUTPUT DEBUG CONSOLE TERMINAL  
  
PS C:\Users\rajas\OneDrive\Desktop\ScaDS> & C:\Users\rajas\anaconda3\python.exe c:\Users\rajas\OneDrive\Desktop\ScaDS\volproportion.py  
Select a ROI and then press SPACE or ENTER button!  
Press the left button to press the ROI button!  
Liquid area 67363.5  
Glass area 232352  
Proportion of liquid in the glass: 0.2899200351191296
```

Volume level

https://github.com/RajasekarSankar/Image_Processing/tree/main/20.04.2023

Machine learning algorithm framework for Volume Estimation

Stage 1

Collect a dataset of images containing liquid with varying levels.

Stage 2

Annotate the images with bounding boxes that indicate the location of the liquid

Stage 3

Train a machine learning model on the annotated dataset to detect the liquid in the images.

Stage 4

Use the trained model to detect the liquid in a new image and calculate its level based on the location of the bounding box

Framework layers

